

FIGURE 1  
(PRIOR ART)




FIG. 2A

51




FIG. 2B

100a




FIGURE 3

100b




FIGURE 4



100




FIG. 6




FIGURE  
7A




FIGURE  
7B




FIGURE  
7C






FIGURE 8B




FIGURE 8A





FIG. 10A is a perspective view of the first embodiment of the device, showing the first arm 100, the second arm 200, and the third arm 300. The first arm 100 is connected to the second arm 200 at joint 311, and the second arm 200 is connected to the third arm 300 at joint 312. The first arm 100 is shown in a retracted position, and the second arm 200 is shown in an extended position. The third arm 300 is shown in a retracted position. The device is shown in a perspective view, with the first arm 100, the second arm 200, and the third arm 300, and the joints 311 and 312.




FIGURE 10A




FIGURE 10B

FIG. 11 is a perspective view of the device 100 in an open position, showing the front panel 102 and the back panel 104. The front panel 102 includes a display 106 and a keypad 108. The back panel 104 includes a camera 110 and a microphone 112. The device 100 is shown in a perspective view, with the front panel 102 and the back panel 104 separated by a hinge 114. The device 100 is shown in a perspective view, with the front panel 102 and the back panel 104 separated by a hinge 114.




FIGURE  
11

FIGURE  
12




FIG. 13 is a perspective view of the keyboard assembly 100 in an open position, showing the keyboard 302 and the display 100. The keyboard 302 is shown in a folded position, and the display 100 is shown in an open position. The keyboard 302 includes a space bar, a shift key, and a control key. The display 100 includes a screen and a touchpad. The keyboard assembly 100 is shown in a perspective view, and the components are labeled with reference numerals.




FIGURE  
13





FIGURE 14

FIG. 14 is a perspective view of the calculator of FIG. 13, showing the calculator in an open position. The calculator is shown in a perspective view, with the keyboard and display visible. The calculator is shown in a perspective view, with the keyboard and display visible. The calculator is shown in a perspective view, with the keyboard and display visible.

**500**



**FIGURE 15**